

接收机 Receiver

产品介绍 Introduction

FS-X8B 是一款专用于多旋翼飞机的双向接收机,采用了 AFHDS 2A(第二代增强版自动跳频数字系统)。它体积小 巧便于安装,可输出标准 PPM 信号和 18 个通道的 i-bus 信 号以及 16 通道的 S.BUS 信号。

Ø

D •

0

FS-X8P

BIND

PPM i.BUS/

S.BUS

VCC

GND

The FS-X8B is a compact 2-way receiver designed for multi-rotor aircraft. It uses the AFHDS 2A (Second Generation Automatic Frequency Hopping Digital System) protocol, supports standard PPM output and has i-BUS support for up to 18 channels, it also supports S.BUS output up to 16 channels.

接收机概览 Receiver overview

ĺΟ

用于连接接收机与模型的各个部件。 PPM 信号接口: 输出标准的 PPM 信号。 i-BUS/S.BUS 信号接口:用于输出 i-BUS/S.BUS 信号

注:接收机将 RSSI 数据转换成 CH14 通道值通过 i-BUS/S.BUS 输出给飞控,信号强度为 0 时对应通道值为 1000,信号强度为 100 时对应通道值为 2000,线性对应相关。

These ports connect the receiver to various models, comonents and flight controllers. PPM signal port: Outputs standard PPM signal. i-BUS /signal port: Outputs i-BUS/S.BUS signal.

Note: The receiver uses CH14 for output of RSSI data to the onboard flight controller via i-BUS/S.BUS. The receiver signal strength data from the onboard flight controller will be displayed as values between 0 and 100 (100 being max signal strength) and the corresponding values displayed on CH14 on the transmitter will be 1000 and 2000 (2000 being max signal strength).

产品规格 Product specification

• 产品型号: FS-X8B

天线

Antenna

- 适用机型: 多轴飞行器
- 无线频率: 2.4GHz
- 无线协议: AFHDS 2A
- 电线类型: 双天线
- 输入电源: 4.0~8.4V
- 数据输出: PPM/i-BUS/S.BUS
- 温度范围: -15℃ -60℃
- 湿度范围: 20%-95%
- 在线更新:
 有
- 外形尺寸: 32*22.5*7.5mm
- 机身重量: 3.7g
- 安规认证: CE, FCC ID: N4ZX8B00

- Product Name: FS-X8B
- Model type: Multi-rotor
- RF: 2.4GHz
- Protocol: AFHDS 2A
- Antenna: Dual Antenna
- Power input: 4.0 \sim 8.4V
- Data Output: PPM/i-BUS/S.BUS
- Temperature Range: -15°C-+60°C
- Humidity Limit: 20%-95%
- Online update: Yes
- Size: 32*22.5*7.5mm
- Weight: 3.7g
- Certificate: CE, FCC ID: N4ZX8B00

对码 Binding

- 将发射机进入对码状态;(发射机进入对码状态的方式可能 不同,请根据发射机的使用说明书进行操作)
- 按住接收机上的对码按键,并为接收机连接电源。接收机上 的指示灯快闪表示接收机进入对码状态;
- 对码成功后,接收机状态指示灯由快速闪烁变为常亮。
- 检查发射机、接收机、模型是否正常工作。如有异常,重复 以上步骤重新对码。
- 1. For information on putting the transmitter into bind mode please refer to the transmitters user manual.
- Power on the receiver while holding the bind button. If the receiver's LED is flashing this means it has entered bind mode.
- If binding is successful the receiver's LED will stop flashing and remain solid.
- Restart the receiver and check to make sure the model and receiver work as expected. If anything does not work as correctly, restart this procedure from the beginning.

http://www.flysky-cn.com Copyright ©2020 Flysky Technology co., ltd





FS-X8B

失控保护 Failsafe

失控保护功能用于在接收机失去信号不受控制后,保 护模型及人员安全。

- 若发射机未设置失控保护通道值输出,接收机在 进入失控状态后均保持最后输出,若发射机设置 了失控保护,则按照发射机通道设置输出。
- This function protects your vehicle by preventing unexpected behaviors in case of signal lost.
 - If the transmitter is not set with failsafe channel value output, all interfaces of the receiver will keep the final output after entering failsafe state; If the transmitter is set with failsafe mode, the output will be set according to the transmitter channel.

▶ 注意事项:

- 使用前必须确保本产品与模型安装正确,否则可能导致模型发生严重损坏。
- 关闭时,请务必先关闭接收机电源,然后关闭发射机。如果关闭发射机电源时接收机仍然在工作,将有可能导致遥控设备 失控或者引擎继续工作而引发事故。
- 确保接收机安装在远离电机,电子调速器或电子噪声过多的区域。
- 接收机天线需远离导电材料,例如金属棒和碳物质。为了避免影响正常工作,请确保接收机天线和导电材料之间至少有1 厘米以上的距离。
- 准备过程中,请勿连接接收机电源,避免造成不必要的损失。

Attention:

- Make sure the product is installed and calibrated correctly, failure to do so may result in serious injury.
- Make sure the receiver's battery is disconnected before turning off the transmitter, failure to do so may lead to
 unintended operation or loss of control.
- Make sure the receiver is mounted away from motors, electronic speed controllers or any device that emits excessive
 electrical noise.
- · Keep the receiver's antenna at least 1cm away from conductive materials such as carbon or metal.
- Do not power on the receiver during the setup process to prevent loss of control.





接收机 Receiver

认证相关 Certification

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

DoC Declaration

Hereby, [Flysky Technology co., ltd] declares that the Radio Equipment [FS-X8B] is in compliance with RED 2014/53/EU. The full text of the EU DoC is available at the following internet address: www.flysky-cn.com.

CE Warning

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

Environmentally friendly disposal

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS



